








# INSTALLATION MANUAL



Cut off power before installation



Max. 100W interconnected



Attention: please check whether the lamp is fixed and wired properly if the lamp doesn't work while switching on.

Please change fluorescent tube in time if the following situation occur:

1. Black spot/ring on two ends of fluorescent tube
2. Rolling lights in fluorescent tube
3. Unstable rays emitted by fluorescent tube